




77881 CONNECTICUT

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside




Dimensions

- A - Seat Depth - 22" / 56cm
- B - Seat Height - 19" / 48cm
- C - Arm Height - 22" / 56cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: Premium elastic webbing offers consistent suspension for the life of the product
- Seat: Interwoven 100% elastic webbing offers consistent suspension for the life of the product
- Back filled with blown fibre



01 Sofa
84 x 38 x 34"
213 x 97 x 86cm
IA: 69" / 175cm



10 Armless Chair
23 x 38 x 34"
58 x 97 x 86cm




33 Swivel Chair
38 x 38 x 33"
97 x 97 x 84cm
IA: 23" / 58cm



02 Chair
38 x 38 x 34"
97 x 97 x 86cm
IA: 23" / 58cm




11 Corner Square
38 x 38 x 34"
97 x 97 x 86cm




35 RHF Corner Chaise
36 LHF Corner Chaise
84 x 38 x 34"
213 x 97 x 86cm



03 Loveseat
61 x 38 x 34"
155 x 97 x 86cm
IA: 46" / 117cm




13 RHF Sofa
12 LHF Sofa
77 x 38 x 34"
196 x 97 x 86cm



40 RHF Sofa Split
39 LHF Sofa Split
89 x 38 x 34"
226 x 97 x 86cm



04 Ottoman
23 x 23 x 17"
58 x 58 x 43cm



14 Armless Loveseat
46 x 38 x 34"
117 x 97 x 86cm



62 Pushback Chair
39 x 37 x 37"
99 x 94 x 94cm
IA: 21" / 53cm



08 RHF Loveseat
07 LHF Loveseat
54 x 38 x 34"
137 x 97 x 86cm



15 RHF Chaise
16 LHF Chaise
30 x 60 x 34"
76 x 152 x 86cm



09 Corner Curve
49 x 49 x 34"
124 x 124 x 86cm



22 Sofabed 60"
84 x 38 x 34"
213 x 97 x 86cm
IA: 69" / 175cm



77881 CONNECTICUT

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty


Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty



4-Seat Corner Sectional with Chaise Lounge

92 x 84"


234 x 213cm



5-Seat Sofa Sectional with Chaise

130 x 60"


330 x 152cm



6-Seat Corner Sectional

115 x 89"


292 x 226cm



3-Seat Sofa Sectional with Chaise

84 x 60"


213 x 152cm



5-Seat Corner Sectional

92 x 89"


234 x 226cm



4-Seat Sofa Sectional with Chaise

107 x 60"

272 x 152cm



5-Seat Corner Sectional with Chaise Lounge

115 x 84"

292 x 213cm