



Dimensions

A - Seat Depth - 22.5" / 57cm B - Seat Height - 19" / 48cm C - Arm Height - 25" / 64cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: Premium elastic webbing offers consistent suspension for the life of the product
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Chaise styling for ultimate comfort and support in full recline
- Toggle power mechanism
- Touch button for power operation
- Seat Fill 1.8 lb high resilience foam for superior comfort without loss of support

Options

- Stainless Steel Cupholder
- Antique Cupholder
- LED cupholder
- Grommet only option available

41638 SPRINGFIELD



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. LHF - left hand facing RHF - right hand facing IA - inside arm to inside



04 Home Theater Ottoman 44 x 28 x 19" 112 x 71 x 48cm




19 Corner Square 44 x 44 x 35" 112 x 112 x 89cm



2P Armless Wide Recliner Pwr 72 Armless Recliner 32 x 42 x 35" 81 x 107 x 89cm



31 Wallhugger Recliner 53 Loveseat Recliner



39 Power Rocker Recliner 42 x 44 x 34" 107 x 112 x 86cm IA: 23" / 58cm



70 Armless Chair 32 x 42 x 35" 81 x 107 x 89cm



B4 Home Theater Wedge, Wd Tbl, USB 17 x 39 x 30" 43 x 99 x 76cm

IA: 46" / 117cm



56 RHF Chaise 57 LHF Chaise 40 x 68 x 35" 102 x 173 x 89cm





36 x 99 x 76cm




W9 Console, USB 14 x 39 x 30" 36 x 99 x 76cm



196 x 107 x 89cm

58 Loveseat Console

68 Loveseat Console





80 x 42 x 35"

43 x 99 x 76cm

75 Sofa Recliner 2/2

203 x 107 x 89cm



Power

76 RHF Recliner

40 x 42 x 35"

5P Sofa Recliner 2/2 Pwr6P RHF Wide Recliner

W8 45 Degree Wedge, USB 36 x 38 x 30" 91 x 97 x 76cm





How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty


41638 SPRINGFIELD



Popular Configurations


Note: Always assemble configurations from right hand facing to left hand facing components.

363 x 178cm









4-Seat Angled Wedge Reclining Sectional

184 x 81"

467 x 206cm


3-Seat Angled Wedge Reclining Sectional 143 x 70"

5-Seat Corner Reclining Sectional 4-Seat HTS Console Separated with HTS Console 129 x 116"

328 x 295cm

Reclining Sectional

185 x 66" 470 x 168cm



5-Seat Corner Reclining Sectional

118 x 118"

300 x 300cm