



Dimensions

A - Seat Depth - 21" / 53cm B - Seat Height - 20" / 51cm C - Arm Height - 24" / 61cm

Features

- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Outside handle mechanism
- Toggle power mechanism
- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort

41066 DANE



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. LHF - left hand facing RHF - right hand facing IA - inside arm to inside



03 Loveseat 62 x 39 x 39" 157 x 99 x 99cm IA: 63" / 160cm



30 Armless Recliner 60 Power Armless Recliner 24 x 39 x 39" 61 x 99 x 99cm



04 Home Theater Ottoman 44 x 28 x 19" 112 x 71 x 48cm



33 Swivel Rocker

39 Power Rocker

35 Wallhugger Recliner

Recliner Chair

31 Wallhugger Recliner 62 x 39 x 39"



09 Corner Curve 47 x 47 x 39" 119 x 119 x 99cm

32 Rocker Recliner Chair 37 Armless Sofabed 54" 46 RHF Recliner Chair

157 x 99 x 99cm





10 Armless Chair 24 x 39 x 39" 61 x 99 x 99cm

47 LHF Recliner Chair

32 x 39 x 39"

81 x 99 x 99cm



22 Sofabed, Queen, 3 Cushion 87 x 39 x 39" 221 x 99 x 99cm



51 Sofa Recliner 61 Power Sofa Recliner 63 Loveseat Recliner 66 RHF Power Recliner 88 x 39 x 39" 67 LHF Power Recliner 224 x 99 x 99cm IA: 63" / 160cm



26 LHF Sofabed 54" 27 RHF Sofabed 54" 74 x 39 x 39" 188 x 99 x 99cm



53 Loveseat Recliner Power 66 x 39 x 39" 168 x 99 x 99cm IA: 42" / 107cm



58 Loveseat Console 68 Loveseat Console Pwr

79 x 39 x 39" 201 x 99 x 99cm



Chair

Recliner

38 x 39 x 39"

97 x 99 x 99cm

IA: 18" / 46cm

A0 11 Degree Storage Wedge

17 x 39 x 36" 43 x 99 x 91cm



A1 45 Degree Storage Wedae 36 x 37 x 36" 91 x 94 x 91cm



A2 Storage Console 13 x 39 x 36" 33 x 99 x 91cm



How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

41066 DANE



Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.



5-Seat Curved Corner Large **Reclining Sectional**

3-Seat Console Separated Angled

Reclining Sectional

105 x 105"

122 x 70"

310 x 178cm

267 x 267cm



5-Seat Curved Corner Small Reclining Sectional with Sofabed

103 x 123"

262 x 312cm




5-Seat Curved Corner Console Separated Reclining Sectional with Reclining Sectional with Loveseat

Sofabed

116 x 123"

295 x 312cm



4-Seat Console Separated Angled **Reclining Sectional**

162 x 74"


411 x 188cm



3-Seat Console Separated **Reclining Sectional**

114 x 66"


290 x 168cm



4-Seat Console Separated Angled

164 x 76"

417 x 193cm



4-Seat Console Separated **Reclining Sectional**

151 x 66"

384 x 168cm