




40625 MORINO

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside



13 RHF Stationary
Sectional End
14 LHF Stationary
Sectional End
46 x 40 x 32"
117 x 102 x 81cm



17 RHF Nest
18 LHF Nest
53 x 40 x 32"
135 x 102 x 81cm



70 Armless Chair
32 x 40 x 32"
81 x 102 x 81cm




72 Armless Wide
Recliner
2P Armless Wide
Recliner Pwr
32 x 40 x 32"
81 x 102 x 81cm



76 RHF Recliner
6P RHF Wide Recliner
Power
77 LHF Recliner
7P LHF Wide Recliner
Power
46 x 40 x 32"
117 x 102 x 81cm



9H Corner Square with
Headrests
43 x 43 x 32"
109 x 109 x 81cm



Dimensions

- A - Seat Depth - 21" / 53cm
- B - Seat Height - 19" / 48cm
- C - Arm Height - 23" / 58cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: Premium elastic webbing offers consistent suspension for the life of the product
- Seat: Interwoven 100% elastic webbing offers consistent suspension for the life of the product



40625 MORINO

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

